




Nintendo Game Boy Advance SP Battery Replacement

This guide contains step by step instructions on how to replace a battery in your Nintendo Game Boy Advance SP.

Written By: Rocco Lattanzio



INTRODUCTION

The battery is a rectangular unit with electrical information printed on one side. It is located on the back of the Game Boy Advance SP.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:

- [Li-ion Nintendo Game Boy Advance SP 3.7V 600mAh Battery](#) (1)

Step 1 — Removing the Battery



- Use a standard Phillips #00 screwdriver to loosen the 4mm screw that keeps the battery cover attached to the device.

Step 2



- Lift the battery cover up and remove it from the device.
- ⓘ The screw will remain attached to the battery cover because of Nintendo's design.

Step 3



- Use your fingers or a plastic opening tool to remove the battery from the device.

For reassembly, follow the instructions in reverse order.

This document was last generated on 2017-10-03 01:39:39 AM.